

### Step 1: Remove the remnants of the old handle

Using a screwdriver prise the remnants of the old handle from the glove box lid. You will see the two retainers either side which held the handle in place, although hardy, take care not to damage these as the new handle fits directly in to these.

This step is easier with the complete glove box removed from the vehicle as you can lever the remnants of the old handle from both sides.

### Step 2: Fit the new handle

Remove the spring from the remains of the old handle and fit on the new handle as illustrated, orientation is important.

Fit the new handle in to the retainers that the old handle used. Click the handle in place one at a time locating in one retainer then pushing in the direction of the second retainer. You will hear the handle click in to place in both retainers.

The legs of the spring will protrude out, use a screw driver (preferably a plastic one to prevent damaging the handle or glove lid) and lever the legs behind the handle.

